Please Note

These "Technical Tips" help sheets aim to answer commonly asked questions in a concise and informative manner - they are for advice & guidance only and do not replace any of the manuals or other literature supplied with our products.

Tip Classification

1. DVRs - Video Tardis
2.

Product : **TARDIS**

Problem : **How do I set only one camera to record using a Video Tardis CCT721 & CCT722?**

Solution :

Ensure display in full screen mode. Press REC button and display will show the four channels. Using the first four keys to the right, set the respective camera to on and the others to off. Now press enter button. Now press record. One camera record led should now light up and not four.

- - - End - - -

Figure 1

Figure 2