


Question: How can I add an extra PTZ camera to an existing CCTV system?

Answer: Add extra cameras including a PTZ to an existing system using the RG59 cabling already installed. The Mule4 allows it to carry the RS485 data along the same RG59 co-ax cable.

**Add a PTZ to an existing system...
..and control it from a different location.**

**3 Video signals in one direction,
1 RS485 signal in the opposite direction.**

CCTV Mule™



Add extra cameras including a PTZ to an existing system using the RG59 cabling already installed. Perfect if you don't have access to run any more cables or even data cables underground!

The clever electronics of the Mule4 allow it to carry the RS485 data along the same RG59 co-ax cable enabling the operator to monitor and control the system from a different location.

This CCTV installation tip is aimed at helping you to install CCTV equipment. If you are looking for answers on "how to fit CCTV" or perhaps "how to network a DVR or NVR" or even "how to get CCTV on your mobile phone" why not check out our full range of CCTV installation tips at: www.systemq.com
How to guides aim to answer commonly asked questions in a concise and informative manner. They are for advice & guidance only and do not replace any of the manuals or other literature supplied with our products.