


**CON822 RJ45 Passive - 4 RJ45 INPUTS 4 BNC OUTPUTS**

**INSTRUCTIONS**



It is possible to send video signals down one CAT5 cable. The CON822 is a useful balun for terminating 4 separate CAT5 radials from balun types CON804 or CON805 in to one 4-way balun.

Whereas co-ax cables are classed as an “unbalanced” mode of transmission, CAT5 twisted pair is known as a balanced mode. In this balanced mode, the two cores carrying the video signal are balanced to a particular reference point and the cable twists enable a uniform rejection of the interference, effectively cancelling it out. To produce a balanced signal BALUNs are used, standing for BALANCED to UNbalanced.

Baluns come in two distinct groups. *Passive* baluns require no power to operate and work up to distances of about 500M although if you are using baluns to send video signals back to multiplexers, quads and DVR it is recommended not to use passive baluns over 200mtrs. *Active* baluns require power for their “active” circuitry and can send video signals over 1Km down low-cost CAT5 cable. Most baluns do not allow you to send power down the CAT5 cable so you will still need to power the camera locally or run another separate cable for power. The CON822 is a passive type balun.

**Using a video balun.**

The balun requires one pair of cores for each of the video signals.



The CON822 balun converts 4 separate RJ45 balun inputs in to 4 standard BNC outputs. Each balun input receives its video signal down a separate CAT5 cable. At the camera end of the cable balun types CON804 (RJ45 connector) or CON805 (terminal strip connector) can be used.

Because a continuous signal is required, baluns cannot send the video through “hubs” or computer “switches” as they work in purely analogue method rather than the digital “packet” method of hubs or switches. This means that you cannot use baluns to send video pictures through existing computer networks that use switches or hubs.

**Step 1-** Run in your CAT5 cable. This needs to be run between your camera and the rest of your CCTV equipment.

**Step 2-** Identify the various pairs within the CAT5 cable. Four pair CAT5 cable has 4 easy to identify pairs. If you have used the new type of CAT5 cable for CCTV then the pairs are even easier to identify.

**Step 3 -** Put on your RJ45 plugs. If you use CON822 and CON804 as a combination then put your RJ45 plug on as per the diagram on the right for both cable ends. If you use the CON805 (terminal strip balun) at the camera end please use the diagram overleaf for the CON805 connections. The CAT5 cable needs to be prepared so that you can slide in the individual cores in the correct order into the RJ45 plug. You need to strip back about 1cm of sheathing to do this and then “fan” out the individual cores so that they will slide into the plug *in the correct order*. There are two diagrams on the right. One is for traditional CAT5 cable; the other is for the new CCTV CAT5 cable. You must take great care making sure you get the cores in the correct order, as this is where mistakes are easy to make.



Once you have the cores in the RJ45 plug, you need to use your crimping tool to make off the end. The crimping tool actually presses the pins into the individual cores and also locks the plug on to the cable. **TIP - make sure all the cores go to the end of the plug or they won't all be crimped!!**



Once you have connected the RJ45 plugs on the cable you can connect the plugs to the CON822 and the CON804, or if CON805 has been used please refer to the diagram below for the CON805 connections. In either case the CON822 is always wired as per the RJ45 diagrams on side A.

**New CAT5 Cable for CCTV****Standard CAT5 Cable**

At the control equipment end of the installation, you have the CON822 balun with four BNC connectors on it. These BNC “video outs” connect to the “video ins” of the equipment you are using, monitors, quad etc.

At the camera end of the CAT5 cable you will either have a CON804 or a CON805, either of them providing a BNC connector for your camera. The CON804/5 can either connect directly to the camera or you will need to run a BNC-BNC cable between the baluns and the cameras. If the cameras do not have BNC connectors and they are the terminal strip type, cut off the BNC plugs and use the centre core of the cable to the video out of the cameras and use the shielding or ground to the negative or ground of the

cameras.

Other than powering and setting up your camera and other CCTV equipment, the installation is complete. Don't forget, this balun does not power the camera so you will still need to do this separately either with a local power supply or another cable.

**Faultfinding.**

A few common questions and answers are listed below. If however you require a COMPLETE instruction set and faultfinding guide for ALL our baluns, you can download this from our web site, [www.planetcc.tv](http://www.planetcc.tv). Alternatively you can use our automated eback service that will automatically email you the information. To use this service send an email to [eback@planetcc.tv](mailto:eback@planetcc.tv) and write **balun instructions** in the subject line. Our automated service will then email you back with our comprehensive balun information package. IMPORTANT - Please note this courtesy information is not available by fax or by post **so please do not call us for it** - you will need to use either the download service or our eback service.

Passive baluns are incredibly reliable as they have no active electronic circuitry and therefore failure of a passive balun is very, very rare. This means if the balun does not work when it is installed you really need to investigate the installation thoroughly.

**No Picture**

1. The wrong core colours have been used in the wrong order, re-check the connection order.
2. The RJ45 plug has not been put on correctly, either the cores are in the wrong order or they are not far enough into the plug and have not been crimped correctly. Make off the end again and re-crimp.
3. There is no power to the camera or the camera is not working. The baluns can only send a video signal down the cable if the video signal is actually there. **Make sure the camera is producing a picture using a test monitor.**
4. The cable is damaged or there is an open circuit or short caused by stretching, clipping or when dragged in. Replace.

**Poor Picture**

1. The RJ45 plug has not been put on correctly, either the cores are in the wrong order or they are not far enough into the plug and have not been crimped correctly. Make off and re-crimp.
2. The camera is not working properly. The baluns can only send a GOOD picture signal down the cable if the camera is producing a GOOD picture to start with. **Make sure the camera is producing a good picture with a test monitor.**
3. Cable run too long. If the CAT5 cable run is too long the picture will deteriorate. 500M is the absolute maximum that the passive baluns will work at and would drive a monitor HOWEVER, equipment such as quads, multiplexers and DVRs require a much stronger signal and therefore restrict passive balun use up to a maximum of 200mtrs with such equipment. A word of caution here – on short runs say less than 100mtrs active baluns can **over** amplify the video signal and cause problems of their own, so passive and active baluns need to be selected correctly for the right job.

**Specifications**

Video inputs/outputs	4
Audio inputs	NONE
Video Bandwidth	12MHz
Power	Passive (not required)
Connections	RJ45– BNC
Max TX distance	500mtrs (to monitor)
Size	80mm x 110mm x 25mm

All specifications are approximate. System Q reserves the right to change any product specification or features without notice. Whilst every effort is made to ensure that these instructions are complete and accurate, System Q cannot be held responsible in any way for any losses, no matter how they arise, from errors or omissions in these instructions, or the performance or non-performance of the camera or other equipment that these instructions refer to. © All contents are subject to copyright, System Q Ltd 2003.