# www.kovert.com Doc > CAM835 External Vandalproof IR Camera with WDR & RS485

# **External Vandalproof IR Camera**

These cameras produce great quality images at a budget price. The cameras are housed in a vandalproof grey housing and are fitted with a 2.8 ~ 12mm varifocal lens and Sony 1/3" Super HAD CCDII sensor providing 650 TVL resolution. The cameras have an OSD menu that can be updated using the RS485 are are especially suitable for low light surveillance in businesses and homes.



# **Features**

Vandalproof IR camera with 42 IR Leds providing up to 40 metre range 650TVL 1/3" SONY Super HAD CCDII 2.8mm ~ 12mm varifocal lens RS485 facility to update menu

# **Mounting the Camera**

The camera is for outdoor mounting on a wall. Secure through the rubber seal using the four screws provided and adjust camera position by releasing the two Phillips screws to adjust horizontal and vertical positions, and then retightening screws. Then adjust the zoom and focus controls using the Allen key. The controls are located below the front of the camera lens. Adjust zoom first then focus.

### **Powering the Camera**

The dome requires a 12V DC regulated power supply. The camera is provided with a fly lead with a mini power jack plug. It is recommended to use a power supply that is rated higher than the current consumption of the camera i.e. the current consumption is 500mA add approximately 50% so use a power supply of 750mA or above.

### Connecting the camera to control equipment.

The dome camera comes with a fly lead for power and video out. To reduce installation time the video out lead is terminated into a male BNC connector. This allows the installer to effortlessly connect the camera to control equipment via a female BNC-BNC lead. Ensure that the Zoom control is adjusted first to compose the required view and locked and then the Focus control to give you a sharp picture.


### RS485 connectivity

An RS485 facility is provided to allow menu updates from a local or remote location so that there is no need to access the camera joystick to change camera settings. RS485 control can be initiated using an RS485 keypad or using the Alien DVR which can be accessed over the Internet using CCTVWindow. This means you can change the settings in this camera from anywhere in the world. The RS485 bare cable has two cores. The brown core is the RS485 plus (T+) and the blue core is the RS485 minus (T-). These connections must be made to the keyboard or DVR, T+ and T- observing matching polarity. Do not connect power to this cable.

# www.kovert.com Doc XCAM833 CAM835 External Vandalproof IR Camera with WDR & RS485

# OSD Menu

The CAM835 has an on screen display menu. This can be accessed using the small joystick controller on the camera flylead.



Press the centre button straight down to enter the menu and use Left, Right, Up and Down to move through and amend menu settings.

The following menu display is shown:



|                 | Lens            | DC / ELC  |  |
|-----------------|-----------------|---|--|
|                 | HBLC / D-WDR    | BLC / HLI / D-WDR   |  |
| EXP             | AGC             | Off / Low / Middle / High   |  |
| Exposure        | 3D DNR          | Off / Low / Middle / High   |  |
| I               | Sense Up        | Auto /Off / x2 / x4 / x8 / x16 / x32 / x64 / x32 / x64 / x128 / x256 / x512 |  |
|                 | Exit            |   |  |
|                 | W B Mode        | ATW / Manual / AWC > Push / AWC   |  |
| WB              | R - Y Gain      | 0~256   |  |
| Colour          | B - Y Gain      | 0 ~ 256   |  |
| Colour          | Exit            |   |  |
| D&N             | D&N Mode        | Auto / Colour / B&W / EXT   |  |
| Day & Night     | Darvinoae       | Auto / Colour / DC W / LAT  |  |
| Duj & Hight     | Mirror          |   |  |
| FUNC Sharpness  |                 |   |  |
| Function        | LSC             | On (0 ~ 30) / Off   |  |
|                 | Motion          | On / Off  |  |
|                 | Area Sel        | Top / Bottom / Left / Right   |  |
| МОТ             | Sensitivity     | 0~30  |  |
| Motion          | Display         | Off / Icon / Trace  |  |
|                 | Hold Time       | $0 \sim 15 \text{ secs}$  |  |
|                 | Alarm           | On / Off  |  |
|                 | Exit            |   |  |
| PVM             |                 |   |  |
| Privacy Masking | Mask 1 ~ Mask 8 | On / Off  |  |
| • •             | Title           | Off / On : 64 characters  |  |
|                 | DPC             | Off / Manual: White or Black 0 ~ 255 / DPC Level 0 ~ 255                    |  |
| SET             | OLPF            | 650 / 850   |  |
| Setup           | Monitor         | CRT / LCD   |  |
|                 | Gama            | 0.45 / 0.60 / 1.0 / User  |  |
|                 | Exit            |   |  |
|                 | Camera ID       | 0 ~ 255   |  |
|                 |                 | Protocol : PELCO-D  |  |
| SYS             | Communi.        | Baud Rate : 2400 / 4800 / 9600  |  |
| System          |                 | Return  |  |
| ·               | Language        |   |  |
|                 | Exit            |   |  |
|                 | Factory Set     |   |  |
| EXIT            | Save & Exit     |   |  |
|                 | Exit            |   |  |
|                 |                 |   |  |

# **EXPOSURE**





LENS DC / ELC DC 쉰 Direct Drive Lens or ELC싄 Electronic Lens

#### E. SHUTTER

AUTO <move joystick Right> 1/50, 1/100, 1/120FLK, 1/250, 1/500, 1/1000, 1/2000, 1/4000,1/10000, 1/100000 AUTO <move joystick Left> X2, X4, X8, X16, X32, X64, X128, X256, X512, X1024.

#### BRIGHT

Set brightness 001 ~ 100

#### DC REF


An Auto Iris requires a DC Reference 000 ~ 020

#### HBLC / D-WDR

OFF / BLC 纪 / HLI / D-WDR 纪








# BLC

Backlight compensation allows you to draw a box in area where there is bright light.

HLI



MODENIGHT / ALL DAYSET LEVEL001 ~ 100GRAY MODEGRAY / D GRAY / BLACKMASK SELECTMASK1 /MASK2 / MASK3 / MASK4

 $000 \sim 020$ 

HBLC LEVEL LOW / MIDDLE / HIGH

### HLI

High Level Backlight Compensation can be set to LOW, MIDDLE or HIGH and is used to reduce strong bright light by drawing up to four mask areas. Particularly helpful for reducing car headlights for number plate

<u>D-WDR</u> ▶D-WDR LEVEL 007 .......... RETURN∔

D - WDR LEVEL

#### D-WDR

Digital Wide Dynamic Range is used to merge light and dark areas using the twin elements in the CCD. This is useful when there is bright light and dark shadows in the picture.

# www.kovert.com Doc XCAM833 CAM835 External Vandalproof IR Camera with WDR & RS485

AGC Automatic Gain Control 94 x 9 4 2 9 OFF / LOW / MID / HIGH DC. C/D-WDR OFF OFF RETURN∔ 3D DNR 3D Digital Noise Reduction OFF / LOW /MID / HIGH / AUTO OFF RETURN∔ When using SENSE - UP noise can be created and this option will reduce its effect. SENSE - UP SENSE - UP RE 本末640 OFF <move joystick left> AUTO - WDR OFF <move joystick right> X2 / X4 / X8 / RETURNŞ X16 / X32 / X64 X128 / X256 / X512 / This feature is the NiteDevil functionality and holds the shutter open slightly longer in order to capture more light. EXIT EXIT Press down to exit menu. **COLOR** COLOR WB MODE / R-Y GAIN / B - Y GAIN / EXIT \*\*\* GAIN WB-MANUAL WB MODE ATW (Auto Tracking White Balance) <move joystick to right> MANUAL 纪 / M.WB R M.WB B RETURN∔ AWC-PUSH / AWC R - Y GAIN Adjust Red Yellow gain 1 ~ 255 (Default 128) B – Y GAIN Adjust Blue Yellow gain 1 ~ 255 (Default 128) M. WB R Manual Red gain M. WB B Manual Blue gain



<u>DAY&NIGHT</u> AUTO 쇤 / COLOR / B&W / EX-CDS 쇤

C\_SUP 000 ~ 100 Default 38 Set to suppress colour noise in night mode

A\_SUP 000 ~ 100 Default 45 Set aperture level suppression in night mode

#### D&N AUTO



#### D&N AUTO

| BURST      | OFF / ON       |
|------------|----------------|
| DAY>NIGHT  | $000 \sim 030$ |
| NIGHT>DAY  | $000 \sim 029$ |
| DWELL TIME | 000 ~ 015      |

Switch on BURST if night time pictures have poor definition. The DAY>NIGHT and NIGHT>DAY settings are for setting the amount of light needed before switching.

Note that these two settings cannot overlap each other and are max/min settings are dependent on each other. Dwell time is the time in minutes where light levels have to be constant before switching commenced.

#### EX-CDS

| BURST      | OFF / ON       |             |
|------------|----------------|-------------|
| DAY>NIGHT  | $000\sim255$   | Default 210 |
| NIGHT>DAY  |                | Default 100 |
| SMART IR   | AUTO 숙소        |             |
| DWELL TIME | $000 \sim 015$ | Default 001 |

Use this option only if using an external CDS sensor for IR light control. Switch on BURST if night time pictures have poor definition.

The DAY>NIGHT and NIGHT>DAY settings are for setting the amount of light needed before switching. Note that there is a wider range of settings for this option. Dwell time is the time in minutes where light levels have to be constant before Switching commenced.

SMART IR 001 ~ 040 Default 010 Adjusts the IR level.

#### EX-CDS



#### SMART IR AUTC



#### **FUNCTION**

| FUNCTION  | © A CONTRACT |
|-----------|--------------|
| WIROR     | OFF          |
| SHARPNESS | 015          |
| MONITOR   | MODE2        |
| GAMMA     | 1045         |
| LSC       | OFF          |
| EXIT      | RETURN∔      |
|           |              |

#### **FUNCTION**

MIRROR OFF / ON Reverse video picture

SHARPNESS 000~030 Default 018 Set sharpness level

MONITOR MODE 1 / MODE 2 Use Mode 2 for LCD monitor or Mode 1 for CRT monitor

GAMMA 0.45 ~ 1.00 Default 0.45

LSC OFF / ON<sup>4</sup> Lens Shading Compensation

EXIT

#### LSC

<u>LSC</u>



#### **MOTION**



SET LEVEL  $0 \sim 30$  Default 010 Lens Shading Compensation compliments the quality of the lens by increasing the gain of the screen angle. Increasing the LSC level will increase the brightness around an object.

### MOTION

This option displays an alarm warning on the monitor to advise that motion has been detected. Up to 4 areas can be set. Can select ICON or TRACE mode and set the time for the warning.

MOTION OFF / ON Switch motion option on or off

AREA SEL AREA 1 ~ 4 Select up to 4 different areas for motion

SENSITIVITY 0 ~ 30 Default 25 Set motion sensitivity

DISPLAY OFF / TRACE / ICON Trace displays selected window in area and ICON displays when motion detected.

HOLD TIME  $0 \sim 15$  Default 3 secs Displays warning for time set

## www.kovert.com Doc XCAM833 CAM835 External Vandalproof IR Camera with WDR & RS485

# **PRIVACY**



#### MASK x



#### PRIVACY

This option allows the setting of up to 8 privacy masking areas that can be opened in up to 8 different colours to mask off areas that are not to be viewed.

MASK 1 ~ 8 ON / OFF

#### MASKx

DOT SEL L\_TOP / L\_BOT / R\_BOT / R\_TOP Sets position of privacy masking area.

DOT XY Draw box size.

MOVE XY Move box to position.

COLOR SET BLACK / GRAY / WHITE / RED / GREEN / BLUE / MAGENTA / CYAN Set box colour.

#### **SETUP**

<u>TITLE</u> OFF / ON Switch on to add a title display up to 64 characters.

- $\leftarrow \ \rightarrow \ \text{When in Modify mode can move text}$
- CLR Removes all text
- POS Move text to a position
- RET Return to previous menu

MANUAL DPC (Dead Pixel Compensation) OFF / MANUAL

This option compensates for dead pixels and can be



SETUP



TITLE



MANUAL DPC WHITE THR White threshold 0 ~ 255 Def 150 BLACK THR Black threshold 0 ~ 255 Def 030 Email: support@koverf.com

Last Revised 18/03/2013



AUTO DPC

Automatically runs dead pixel compensation



<u>OLPF</u> 650 / 850 Optical Low Pass Filter is used to blur straight lines by 1 pixel Set 650 for IR cut filter or 850 for IR-PASS

<u>OSD COLOR</u> BLUE / GREEN / RED / WHITE / BLACK / GRAY / MAGNETA / CYAN

#### **SYSTEM**



COMMUNICATION

BAUDRATE

PELCO-D 9600

#### **SYSTEM**

This menu allows the use of the RS485 connections on the camera to change the menu settings. There is also an option to change the language for the menu.

<u>CAMERA ID</u> 000 ~ 255 Default 001 Ensure each camera accessed by RS485 has a unique ID number set.

<u>COMMUNI</u> OFF / ON Set to allow RS485 connection and change baud rate.

LANGUAGE ENGLISH / CHINESE / JAPANESE / ITALIAN / RUSSIAN / PORTUGUESE / SPANISH / GERMAN / FRENCH

PROTOCOL PELCO-D

BAUD RATE 2400 / 4800 / 9600 / 19200

Email: support@kovert.com

Doc XCAM833

# **RS485 Menu Control**

Using the RS485 to change menu settings can be a good option. Note the zoom and focus are manually set but all the menu settings can be changed using the RS485. The Alien DVR can be used to control access by using the PTZ option. This means if you run a CAT5 single matched pair from the camera to the DVR you can update the menu, from the DVR rather than having to use ladders to access the camera. A further benefit is if the DVR is remotely networked, you can update the menu from a remote location using the Alien client software. This is especially useful when installations are a long distance away, saving you transport and of course changes can easily be made when dark.

To enable control of the RS485 connection using a PTZ keyboard or Alien DVR, you need to do the following:

a) Connect a CAT5 match twisted pair to the Brown (positive) and Blue (negative) RS485 camera terminal connector ensuring the + and – connections are correctly connected on the keypad or DVR. On the Alien DVR the T+ refers to the + and the T- refers to the – connections. The control works only on the PELCO-D setting and this must be set in the DVR PTZ menu for the correct channel. Also the baud rate must be set ( recommend 2400) in the DVR and in the COMMUNI option in the camera SYSTEM menu. Also ensure the Camera ID set in the camera menu is the same as the ID in the PTZ menu.

b) Enter a CALL 95 via the DVR or keypad to display the menu. The arrow keys move up, down, left and right in the menu. The right arrow changes values and IRIS + will enter submenus and save settings.

Note that various keypads may have different keys allocated and the above is only a guide.

| Camera Specifications |                               |  |  |  |
|-----------------------|-------------------------------|--|--|--|
| CCD                   | 1/3" SONY Super HAD CCDII     |  |  |  |
| Resolution            | 650TVL - 752(H) x 582(V)      |  |  |  |
| Auto Shutter          | PAL: 1/50s ~ 1/100,000s       |  |  |  |
| IRs                   | 42 x IRs up to 40 metre range |  |  |  |
| Video Output          | 1v p ~ p, 75Ω                 |  |  |  |
| Power/Current         | 12vDC (± 10%) 450mA           |  |  |  |
| Lens                  | 2.8 ~ 12mm Varifocal Lens     |  |  |  |
| Weatherproof          | IP66                          |  |  |  |
| OSD Menu              | RS485 and joystick access     |  |  |  |
| WDR                   | Wide Dynamic Range facility   |  |  |  |
| NightDevil            | Sense Up feature              |  |  |  |
| S/N Ratio             | More than 50dB                |  |  |  |
| IR Power On           | CDS auto control              |  |  |  |
| Operating Temp.       | -10°C ~ +45°C                 |  |  |  |
| Dimensions            | 215mm(L) x93mm(W)x 175mm (H)  |  |  |  |
| Weight                | 1700gms                       |  |  |  |
|                       |                               |  |  |  |

# **Camera Specifications**

All specifications are approximate. Kovert.com reserves the right to change any product specification or features without notice. Whilst every effort is made to ensure that these instructions are complete and accurate, kovert.com cannot be held responsible in any way for any losses, no matter how they arise, from errors or omissions in these instructions, or the performance or non-performance of the camera or other equipment that these instructions refer to.



This symbol on the products and/or accompanying documents means that used electronic equipment must not be mixed with general household waste. For treatment, recovery and recycling please return this unit to your trade supplier or local designated collection point as defined by your local council.

WEE/CG0783SS