

SEE560(W) Internal Varifocal Dome Camera (2.8 ~ 12mm) Lens The SEE560 has multi format HD modes for TVI, AHD, CVI and CVBS and a separate BNC for CVBS* (analogue) use.

Features:

Multi format TVI/AHD/CVI/CVBS
plus separate BNC for CVBS*
2.1 MegaPixel sensor
3 MegaPixel 1080P/700TVL (CVBS)
2.8 ~ 12mm lens
22x IR LEDs 20m range
Privacy masking & Motion Detection
Plastic construction
Wide Dynamic Range
Sens-Up for improved night vision



Special Features

The SEE560 cameras produce exceptional quality images using a 2.1 MegaPixel 1/2.9" sensor providing HD 1080P resolution.


The SEE560 is a multi-format HD camera with TVI, AHD, CVI and CVBS mode selection and in addition a separate analogue output (CVBS) on a separate BNC lead. * Additional CVBS output available if using HD, but only one CVBS if not.

In HD-TVI mode the cameras have the Coaxitron Control facility for changing the OSD menu specifications via the DVR or remote network connection, or via the camera joystick.

This camera has the Sens-Up menu feature for reducing shutter speed for improving

Mounting the Camera

The camera is an internal camera for mounting on a ceiling and has a 2 way gimbal. The connection cable is through the rear side of the white camera base or through the black base knock-out if required. To mount camera first remove the dome cover by pushing in the base retaining clip that is located just above where the cable emerges. You will see an arrow marking just above it. Pressing this in will release the dome cover.






Now turn the camera around so that you face the lens. You will see that the black inner base is held in position by a locking clip.

Pull the locking clip away from the inner black base and twist the black base to remove it.

Now secure the black base to the ceiling. Then refit the white base. Do not refit dome cover until you have powered the camera as you need to adjust the Zoom and Focus controls. Position the camera lens by twisting the camera in the base and loosen the screws for the lens mount to adjust the vertical position. Now retighten screws.



Powering the Camera

The SEE560 draws 12V DC 300mA when IRs are on, and power consumption is rated at 3.6 watts. It should be noted that extra headroom is required when the camera is first powered up so we recommend connecting it to a 12v DC regulated minimum 400mA power supply. The camera is provided with a fly lead with a mini power 2.1mm DC socket. The camera is polarity sensitive so connections must be correctly made.

Connecting the camera to control equipment

The dome camera comes with a fly lead for power, TVI/AHD/CVI/CVBS selected BNC video output plus a second analogue (CVBS) video output on a separate BNC lead. Connect the HD camera to control equipment via a female BNC-BNC lead. When using a co-ax type cable such as RG59 or similar, the outer braid of the co-ax provides the "0V GROUND" connection and the inner core provides the "Video" connection. The separate analogue (CVBS) output is primarily available for setup purposes but can be used for viewing via an analogue monitor. Note that you cannot use both analogue outputs together but can view one analogue and one HD.


These cameras can be viewed in TVI, AHD, CVI and CVBS. First power the camera up when it is connected to a monitor or DVR and monitor, and see if the required format displays a colour picture. If not, press the joystick button in and not down, for 3 seconds. Repeat until picture displays in colour and is sharp. (Note that picture may be in b/w in low light levels or the cellophane lens cover has not been removed).

Alternatively if you use the menu, you can change the camera format in the menu:

Example - Change camera format to TVI:

<System> <Output> <MAIN OUTPUT ANALOG OUT0

<System> <Output> <ANALOG OUT0 TVI ←



When you are in correct format, press the joystick button in, momentarily, if you wish to access the menu.




Manual Zoom and Focus

This camera has a 2.8 ~ 12mm vari-focal lens and is adjusted manually. There are two adjusters on the lens and they are marked T and W for Tele and Wide Zoom, and N and F for Near and Far Focus. Adjust the Zoom (T and W) first by first slackening the adjuster off with a screwdriver and lock down when all areas of picture viewed are captured albeit out of focus, and then adjust Focus (N and F) to get sharpest picture. There is a digital correction for sharpness in the camera menu. Only use that, when the best optical picture is acquired.


Menu Access via TVI DVR using Coaxitron

Access to the camera menu is via the menu buttons on the camera or via the Up the Co-ax connection. Access by the menu buttons is described below. To use the Up The Coax connection, this can be accessed using the PTZ menu in the MEGA TVI or MAX TVI DVRs using the AlienTVI(Coaxitron) protocol. This protocol is generally set in the PTZ Settings menu as default but if not, select using the following:

Enter the DVR Menu, click on Video, PTZ and select the channel number of the TVI camera connected to the DVR. Then click on PTZ Settings and select AlienTVI(Coaxitron) and click OK.



Now click on the **PTZ** button at the bottom of the screen and a full screen picture will be displayed with the PTZ control menu. Click on the **IRIS**+ button to display menu




Use the directional arrows to move up and down or left or right to select options.



OSD Menu

The SEE560 has an on screen display menu. This can be accessed using the joystick on the camera.



Press the centre button straight down (see arrow) to enter the menu and use Left, Right, Up and Down to move through and amend menu settings.

Alternatively use the TVI DVR PTZ menu as detailed in "Menu Access via DVR" above.

The following menu display is shown:

IRIS	ELC ALC	Electronic Light Control – overall brightness of picture Auto light compensation – measures peak light levels
FOCUS ADJ	OFF ON J	Focus Area Wide / Narrow / Middle (Def Wide) Disp Tone (Display Tone 0 Low, 1 Medium, 2 High Disp H_Pos 0 ~ 60 Horizontal Position (Def 2) Disp V_Pos 0 ~ 34 Vertical Position (Def 12) Disp H_Size 0 ~ 60 Horizontal Size (Def 2) Disp V_Size 0 ~ 34 Vertical Size (Def 14) Return
EXPOSURE 🕹	BRIGHTNESS SHUTTER SENS-UP AGC RETURN	0 ~ 20 (Def 10) Auto
BACKLIGHT	OFF HLC BLC WDR SPECIAL NOTE: IF USING WDR YOU WILL LOSE ANY CVBS CONNECTION	Level 1 ~ 20 / Color — BLK/Customise/WHT/YEL/CYN/GRN/MAG/RED/BLU H-Pos — V-Pos — H-Size — V-Size - Return Normal / ROI



	Ī	
DAY&NIGHT	EXTERNAL 🗸	IR LED Off / On (IRs cannot be switched off) Anti-Sat. 1 ~ 20 Default 10 (Not used when IRs off) Extern S/W Low / High D->N Level 1 ~ 20 Default 13 N->D Level 1 ~ 20 Default 7 Delay - Low / Middle / High - Return
	AUTO COLOUR B&W	IR LED Off / On (IRs cannot be switched off) Anti-Sat. 1 ~ 20 Default 10 (Not used when IRs off) AGC Threshold 1 ~ 20 AGC Margin 1 ~ 20 Delay – Low / Middle / High - Return IR LED Off / On (IRs cannot be switched off)
		Anti-Sat. 1 ~ 20 Default 10 (Not used when IRs off) Return
COLOR 🎜	AWB Auto Color Gain 1 ~ 20 (Default 13) Return	AUTOext / Preset (Push) Color Gain 1 ~ 20 Default 13 Return MANUAL C-Temp 5000K / 8000K / 3000K R-Gain 1 ~ 20 (Default 10) B-Gain 1 ~ 20 (Default 10) Return
DIGITAL NOISE REDUCTION	DNR	Off / Low / Middle / High
IMAGE	SHARPNESS GAMMA MIRROR FLIP ACE DEFOG PRIVACY	CVBS / CVI / TVI / AHD - 1 ~ 10 TVI Default 4 0.55 / 0.65 / 0.75 / 0.45 Off / On Off / On Off / Low / Middle / High (Adaptive Colour & Contrast Enhancement) Off / On ✓ Mode – Auto / Manual Level - Low / Middle / High Off / On ✓ Zone Num (0 ~ 15) / Zone Disp Off / On H-Pos / V-Pos / H-Size / V-Size / Y-Level (1 ~ 20) / CR Level (1 ~ 20) CB Level (1 ~ 20) / Return TRANS (0 ~ 3) Return



MOTION	OFF / ON	Window Zone 0 ~ 3 Window Use On/Off Det H-Pos <nn> <nn> value = position Det V-Pos <nn> <nn> value = position Det H-Size <nn> <nn> value = size Det V-Size <nn> <nn> value = size Return Det Tone 0 ~ 4 MDRect Fill On/Off Sensitivity 0 ~ 10 (Default 5) Motion OSD On/Off Text Alarm On/Off Signal Out Off/On Return</nn></nn></nn></nn></nn></nn></nn></nn>
SYSTEM	FRAME RATE FREQUENCY COM.	Main Output Analog Out 0
	IMAGE RANGE FULL / COMP / USER COLOR SPACE AUDIO MIC COLOR BAR LANGUAGE CAM TITLE RESET ON(Push)	IMAGE RANGE Offset 0 ~ 32 (Default 16) Return HD-CbCr / YUV / SD-CbCr (Not Used) Off / On ENG / CHN / CHN(S) / JPN / KOR Off / Right Up
EXIT	Press IRIS + to exit	



Menu Description

The following menu description gives more in depth information about the menu options. In some instances recommendations are made to hopefully enhance the results. However every installation will be different and there will occasions when alternative solutions may be more suitable.

	ELC	Electronic Light Control – measures overall brightness
IRIS	ALC	Auto light compensation – measures peak light levels

ELC Electronic Light Control – measures overall brightness of picture and applies to manual iris lens

ALC Auto light compensation – measures peak light levels and applies to auto iris lens which this camera has.

Recommendation is to set ELC

		Focus Area Wide / Narrow / Middle (Def Wide)
	OFF	Disp Tone (Display Tone 0 Low, 1 Medium, 2 High
FOCUS ADJ	ON 🎝	Disp H_Pos 0 ~ 60 Horizontal Position (Def 2)
		Disp V_Pos 0 ~ 34 Vertical Position (Def 12)
		Disp H_Size 0 ~ 60 Horizontal Size (Def 2)
		Disp V_Size 0 ~ 34 Vertical Size (Def 14)
		Return

Focus Area Middle / Wide / Narrow Select to create a focus box

In the camera menu you can enter the Focus Adjust option and select and area for best focus result by creating a box (Wide, Middle or Narrow) to select the required area for focusing. These 3 bars means sharpness, from left to right means from low frequency to high frequency, or from wide range to narrow range sharpness. Green stands for the former highest sharpness, Yellow stands for the present highest sharpness. Note that this is a setup aid for manual focusing and only applies when manual vari-focal lenses are used . Ensure option is switched off after setup.

Disp Tone 0/1/2 (Alter brightness of focus aid)

Disp H _ Pos (Set horizontal position of Focus Box)

Disp V Pos (Set vertical position of Focus Box)

Disp H _ **Size** (Set horizontal size of Focus Box)

Disp V _ **Size** (Set vertical size of Focus Box)

RETURN

Return to Main Menu



EXPOSURE 🗸	BRIGHTNESS SHUTTER	0 ~ 20 (Def 10) Auto
	AGC RETURN	0 ~ 10 (Def 10)

BRIGHTNESS $1 \sim 20$ (Default = 10)

Use this setting to increase brightness by opening camera iris. Useful for improving night time viewing by using in conjunction with the Sens-Up option. However be aware to consider possible effects when there is strong sunlight in summer that if setting brightness to high it may cause the picture to white out.

Recommendation is to set brightness to 15.

SHUTTER Auto / Manual

1/25,1/50,1/100,1/200,1/400,1/800,1/1600,1/3200,1/6400,1/12800,1/25600, Flicker

Shutter speed changes allow you to freeze moving objects without ghosting but reduce the amount of available light the faster the shutter operates. At night the slower the shutter speed the more light is available. The Flicker option sets the shutter speed at 1/250 that synchronises with fluorescent tubes so that the pulsing effect is minimised.

Recommendation is to leave this in Auto.

SENSUP Off /x2/x4/x8/x16/x32

The SensUp option allows the shutter speed to be reduced allowing additional light to be captured. Increasing brightness helps night time viewing (see BRIGHTNESS setting above). If set too high and SensUp is slowing shutter speed down to a lower speed than any movement speed, ghosting can occur

Recommend that SensUp is switched to x2 or greater but higher settings can cause ghosting.

AGC $1 \sim 20$ (Default = 10)

For better performance in low light conditions the AGC (Automatic Gain Control) can be increased. This has the effect of making the picture brighter but it may also add more noise as it amplifies all aspects of the video signal. Snowy pictures can be caused when SensUp levels are increased.

Recommend AGC is decreased below 10 if Sensup is set. Set to 9 if SensUp x2.

RETURN

Return to main menu.



BLC WDR H-Pos - V-Pos Normal / ROI - SPECIAL NOTE: IF USING WDR YOU WILL LOSE ANY CVBS CONNECTION H-PO H-SIZ V-SIZ Return	/WHT/YEL/CYN/GRN/MAG/RED/BLU - H-Size – V-Size - Return (Region of Interest) ow Zone 0 ~ 3 ow Use ON / OFF S 320 S 180 ZE 512 ZE 432
---	--

Backlight Compensation when set, can balance light levels during day and night so that light hitting objects viewed, is evenly spread across the picture. There are three options HLC, BLC and WDR that can be selected.

HLC •

(High Level Backlight Compensation)

Level 1 ~ 20 / Mode – All Day / Night Only

HLC is high level backlight compensation that will darken a bright area e.g car headlights. This can be set for all day or night only. The lower the level the more compensation is applied. Note that using the night option may be best as daytime pictures generally give a more even spread of light apart from sunlight issues.

Recommend only to use on Night Only if bright lights are causing complete video loss.

BLC **J**

(Backlight Compensation)

BLC is the standard setting for low level light differences. Select an area where BLC is required. Using the H-Pos (Horizontal Position) and V-Pos (Vertical Position) followed by H-Size (Horizontal Size) and V-Size (Vertical Size) create a box where light balancing is required.

WDR 🌙

(Wide Dynamic Range) Normal / ROI (Region of Interest) / Weight – Low / Middle / High WDR is used for surveillance applications where there is a large difference in foreground and background light levels. Without the option switched on, views by cameras looking through windows may not give good reproduction outside. Also where there are areas of shadow and bright sunlight, the WDR option helps to balance light levels. ROI provides an option to create up to 4 areas using WDR rather than applying to the whole picture.

Recommend using WDR where balancing light levels in warehouses or large buildings is difficult. Also helps when light is entering a window or door entrance.

Return

Return to main menu



DAY&NIGHT	EXTERNAL 🎝	IR LED Off / On (IRs cannot be switched off) Anti-Sat. 1 ~ 20 (Not used when IRs off) Extern S/W Low / High D->N Level 1 ~ 20 Default 13 N->D Level 1 ~ 20 Default 7 Delay – Low / Middle / High - Return
	AUTO	IR LED Off / On (IRs cannot be switched off) Anti-Sat. 1 ~ 20 (Not used when IRs off) AGC Threshold 1 ~ 20 AGC Margin 1 ~ 20 Delay – Low / Middle / High - Return
	B&W J	IR LED Off / On (IRs cannot be switched off) Anti-Sat. 1 ~ 20 (Not used when IRs off)
	B&W ◆	· ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` `

Day & Night menu controls light settings and predominantly provides options for using the cameras' Infra-Red facilities. There are four sub-options namely External, Auto, Colour and Black & White. The option to switch off IRs is not available in this camera.

EXTERNAL •

This option does not use the internal CDS sensor to measure the available light. With cameras using their own IR light source, this option can give the best results. Note that this option has a manual adjustment for setting IR switch on according to lux level from day to night and from night to day, plus an option for applying a delay factor. This stops switching until a pre-determined lux level remains constant.

Recommend to try this option if Auto does not give required results.

AUTO 🤳

The standard Auto function uses the internal CDS to measure available light. This uses AGC (Automatic Gain Control) and Anti Saturation to measure picture quality before switching which is used in conjunction with a pre-determined time interval when lux levels remain constant.

COLOUR

This option will remain in colour mode day and night. There are no sub menu settings. This will only be applicable when light levels at night allow the camera to continue working at 4 lux or higher.

B&W ✓

When this option is selected the camera will remain in black and white mode, day and night. The only sub menus available are Anti Saturation.

Return

Return to main menu.



COLOR 🞜	AWB Auto Color Gain 1 ~ 20 (Default 13) Return	AUTOext / Preset (Push) Color Gain 1 ~ 20 Default 13 Return MANUAL
		C-Temp 5000K / 8000K / 3000K R-Gain 1 ~ 20 (Default 10) B-Gain 1 ~ 20 (Default 10) Return

This feature automatically adjusts the colour settings in the camera to match the type of light available, so that white and other colours appear as natural as possible.

AUTO

This option automatically sets white balance.

AUTOext

This option is generally used to set white balance when camera is used externally.

PRESET(Push) Press IRIS+ or joystick centre button down

This option allows you to set white balance using current light levels. Settings will only change when you press IRIS+ or joystick centre button down.

MANUAL **✓**

Use this option to manually balance light levels. Note that the manual option is used for a static light environment and generally suitable for cameras installed indoors using constant artificial light.

C-Temp 5000K / 8000K / 3000K R-Gain 1 ~ 20 (Default 10) Sets Red Gain B-Gain 1 ~ 20 (Default 10) Sets Blue Gain Return

RETURN

Return to main menu

DIGITAL NOISE	DNR	Off / Low / Middle / High
REDUCTION		

DNR Off / Low / Middle / High

Digital Noise Reduction is generally applied when the Sens-Up feature is used to improve night time views in low light conditions. Using the Sens-Up option slows the shutter speed but this increases noise and causes grainy picture effects. DNR helps to minimise this effect. The options low, medium and high, apply different levels of noise reduction and therefore have to be tested to gain the best result as light levels will be different at every site and location.

Recommend to leave off even when Sense-Up is on and if grainy picture is created then test starting at low, and leave camera on the best setting.



IMAGE	SHARPNESS 🖊	CVBS / CVI / TVI / AHD - 1 ~ 10 TVI Default 4
	GAMMA	0.55 / 0.65 /0.75 / 0.45
	MIRROR	Off / On
	FLIP	Off / On
	ACE	Off / Low / Middle / High (Adaptive Colour &
		Contrast Enhancement)
	DEFOG	Off / On 🎜 Mode – Auto / Manual
		Level - Low / Middle / High
	PRIVACY	Off / On ✓ Zone Num (0 ~ 15) / Zone Disp Off /On
		H-Pos / V-Pos / H-Size / V-Size /
		Y-Level (1 ~ 20) / CR Level (1 ~ 20)
		CB Level (1 ~ 20) / Return
		TRANS (0 ~ 3)
		Return
	RETURN 🗸	

IMAGE ✓

The Image menu covers a variety of options including sharpness, mirror, defog, shading and privacy masking facilities.

Sharpness (1~10 for CVBS / CVI / TVI / AHD)

Depending on the camera format selected, the format/s will be in dark type for adjustment. The sharpness control is done by digital correction and the best way to set this option is to set level to maximum of 10, then flick back to 1, to see the difference. Then adjust to display sharpest picture without displaying heavy black lines around subjects. Only use after the best setting optically is achieved using the camera focus control.

Gamma 0.55 / 0.65 / 0.75 / 0.45 (Default 0.55)

Gamma correction controls and adjusts the overall brightness of an image.

Recommend trying each option and select best quality picture

Mirror Off / On

This option changes a left handed view to a right handed view if switched on.

Flip Off / On

This option turns a view upside down. This option is generally used with the Mirror function.

ACE Off / Low / Middle / High

Adaptive Colour & Contrast Enhancement (ACE) is an automated option for adjusting colour and contrast as light levels changes through the day. Low, middle or high options are available.

Recommend setting option to Low

DEFOG Off / On

The defog option can be used to improve the captured image in poor weather conditions such as smog, fog or smoke. Three levels of optimisation can be applied, low, middle or high. This option is useful to stabilise rapid fluctuating light levels.

Recommend setting this option to On



PRIVACY Off / On 🌙

Zone Num $(0 \sim 15)$ This function allows the creation of up to 16 coloured areas to be created to provide privacy masking.

Zone Disp Off /On The Zone Display allows you to switch on and off the zone number.

H-Pos / V-Pos / H-Size / V-Size

Each area can be positioned using the H-Pos (horizontal position), VPos (vertical position) and sized using the H-Size (horizontal size) and V-Size (vertical size) options. The Zone Display allows you to switch on and off the zone number.

Y-Level (1 ~ 20) CR Level (1 ~ 20) CB Level (1 ~ 20)

The Y-Level is the colour hue for privacy masking and the CR Level (Chrominance Red) and CB Level (Chrominance Blue) are used to create the required colour.

The pictures below show an area that has been masked, before and after.





TRANS $(0 \sim 3)$ Set the transparency level of the masked areas.

RETURN

Return to main menu



Return	MOTION	OFF/ON 🗸	Det Window Window Zone 0 ~ 3 Window Use On/Off Det H-Pos <nn> <nn> value = position Det V-Pos <nn> <nn> value = position Det H-Size <nn> <nn> value = size Det V-Size <nn> <nn> value = size Return Det Tone 0 ~ 4 MDRect Fill On/Off Sensitivity 0 ~ 10 (Default 5) Motion OSD On/Off Text Alarm On/Off Signal Out Off/On Return</nn></nn></nn></nn></nn></nn></nn></nn>
--------	--------	----------	---

MOTION Off / On J

The motion option when switched on allows you to create up to four areas in the picture and as motion is detected in these areas, the areas will be displayed with red moving boxes.

DET WINDOW	4	Enter to select window number

Window Zone 0 ~3 Window Use On / Off

Det H-Pos<nn>Set horizontal positionDet V-Pos<nn>Set vertical positionDet H-Size<nn>Set horizontal sizeDet V-Size<nn>Set vertical size

Each area can be positioned using the H-Pos (horizontal position), VPos (vertical position) and sized using the H-Size (horizontal size) and V-Size (vertical size) options.

Return

DET TONE $0 \sim 4$ Sets the background tone to enable the motion detect

area to be more or less prominent.

MDRECT FILL On / Off Allows the switching on or off of the selected zone

SENSITIVITY 0 ~ 10 Sets the sensitivity of the motion detection

MOTION OSD On / Off Switch Motion On Screen Display on or off

TEXT ALARM On / Off Switch Motion Text Alarm on or off.

Return



SYSTEM	OUTPUT 🎜	Main Output Analog Out 0	
	FRAME RATE	1080 25P	
	FREQUENCY	50Hz / 60Hz	
	COM.	COM	
	•	Cam ID 0 ~ 255 Default 0	
		Baudrate 2400 / 4800 / 9600 / 57600 / 115200	
		Set Done On (push)	
		Return	
		FULL / COMP / USER	
		Offset 0 ~ 32 (Default 16) Return	
	IMAGE RANGE	Return	
	FULL / COMP / USER	IMAGE RANGE	
	TOLLY COM YOULK	Offset 0 ~ 32 (Default 16)	
		Return	
COLOR SPACE AUDIO MIC		HD-CbCr / YUV / SD-CbCr	
		(Not Used)	
	COLOR BAR	Off / On	
	LANGUAGE	ENG / CHN / CHN(S) / JPN / KOR	
	CAM TITLE	Off / Right Up / Left Down ✓	
		(Use up or down to select character and	
	DECET ON/Decale)	left or right to select position)	
	RESET ON(Push) Return	Hold down Iris+ button for 3 seconds	
	Keturii		

The SYSTEM menu provides a number of general facilities. These include selecting the correct camera format, setting a camera identification number and baud rate for RS485 connection, resolution mode, frame rate and colour standard, language, test colour bar, camera title and camera reset option.

Main Output Analog Out 0 /1	(Out $0 = HD$ Out $1 = CVBS$)
Analog Out 0 TVI J (Select	ΓVI / AHD / CVI)
Y Gain 0 ~ 32 Default 16	Yellow Gain
CB Gain $0 \sim 32$ Default 12	Blue Gain
CR Gain $0 \sim 32$ Default 12	Red Gain
Position $0 \sim 256$ Default 128	Position
Burst Freq 0 ~ 256 Default 128	Burst Frequency
Burst Gain 0 ~ 128 Default 69	Burst Gain
UCC Select0 8 Byte (Do not ch	ange this)
720 EX Off/ On	
UCC Select1 not used	
Exit	
	Analog Out 0 TVI (Select Y Gain 0 ~ 32 Default 16 CB Gain 0 ~ 32 Default 12 CR Gain 0 ~ 32 Default 12 Position 0 ~ 256 Default 128 Burst Freq 0 ~ 256 Default 128 Burst Gain 0 ~ 128 Default 69 UCC Select0 8 Byte (Do not ch 720 EX Off/ On UCC Select1 not used



Analog Out1 CVBS

Return

FRAME RATE 1080 25P / 720 25P / 720 (Crop) 50P (Select camera frame rate)

Sets the camera output mode. 1080P is default.

FREQ 50Hz / 60Hz (Cycles per second)

COM. J Cam ID 1 (Set ID number in camera between 0 and 255)

Baud Rate 2400 / 4800 / 9600 / 57600 /115200

Set Done (Press Iris+ button)

Return

Offset $1 \sim 32$ (Default = 16)

Return

COLOR SPACE HD-CbCr (High Definition Chrominance Blue and Red)

YUV (Allows grayscale adjustment (Y= luminance UV= colour) SD-CbCr (Standard Definition Chrominance Blue and Red)

AUDIO MIC Not used

COLOR BAR Off / On (Useful for testing camera colour quality)

LANGUAGE ENG / CHN / CHN(S) / JPN / KOR (Select language required)

CAM TITLE Off / Right Up

✓ / Left Down

✓ (Enter camera title)

(Use up or down to select character and left or right to select position) Hold down Iris+ button for 3 seconds



RESET ON(Push)✓ Press IRIS+ or joystick centre button down

Return

Email: support@kovert.com

EXIT	SAVE J CANCEL J	Press IRIS + to exit Press IRIS + to cancel and exit without saving



SEE560 Camera Specifications

Sensor	2.19 MP sensor	Video Outputs	TVI, AHD, CVI & Analogue
Resolution 1080p 1920(H) x 1080(V) @ 30fps		Independent CVBS	CVBS 700TVL separate output *
HD distance	HD distance Stnd BNC 75ohm cable up to 500m		18 IR LEDs < 20m
Lens	2.8 ~ 12mm vari-focal lens 3 MPX	Operating Temp.	-10°C ~ +50°C
Min.Illumination	Colour 0.5 Lux @ F2.0, AGC On	Power/Current	12vDC 300mA IRs On
Mounting	nting Ceiling mounting		12vDC 400mA Minimum
Menu	Menu OSD direct and via coaxitron		HLC, BLC, WDR, Off
WDR	WDR Wide Dynamic Range option		130mm (d) x 95mm (h)
S/N Ratio	/N Ratio $\geq 52 dB \text{ (AGC Off)}$		Plastic
Colour	White base, black shroud, clear cover		No Rating Indoor camera
NiteDevil	Sens-Up option included	Noise Reduction	2DNR and 3DNR low/mid/high
Privacy Masking	ivacy Masking 16 areas for Privacy Masking		Automatic/Selectable
Mirror/Flip	ror/Flip Off / On		On/Off 4 detection zones

^{*} ONLY ONE ANALOGUE OUPUT DISPLAYS AT ANY TIME



WEE/CG0783SS

This symbol on the products and/or accompanying documents means that used electronic equipment must not be mixed with general household waste. For treatment, recovery and recycling please return this unit to your trade supplier or local designated collection point as defined by your local council.

All specifications are approximate. Kovert.com reserves the right to change any product specification or features without notice. Whilst every effort is made to ensure that these instructions are complete and accurate, kovert.com cannot be held responsible in any way for any losses, no matter how they arise, from errors or omissions in these instructions, or the performance or non-performance of the camera or other equipment that these instructions refer to.